

ANTENNA MOUNT MB ATEGO-VW DELIVERY PASSENGER/DRIVER

AP3370 AP3368



Area where the mount must be fastened, either on the passenger side or the driver side.



The mount will be fastened with the screw located between the bumper and the truck's front fairing.



Position the mount and tighten the screw firmly so it does not come loose due to truck vibration.



Your STEELBRAS mount is now ready to receive the CB Mobile Antenna 1/4 Wave.



The **AP3370** and **AP3368** mounts were designed to be installed on the front of MERCEDES-BENZ ATEGO and VOLKSWAGEN DELIVERY trucks, passenger side AP3370 or driver side AP3368. Use the screws already on the trucks.

QUALITY: All

mounts in our line are galvanized before painting (oven-cured powder coating at over 200°C). Greater strength,

longer service life.



Use the STEELBRAS Mounting Kit **AP0016** for better installation of your antenna on the mount.

(Not included with the product)



steelbras
soluções em antenas

® Av. Cidade Fukuyama, 725 - CEP 19064-210 - Pres. Prudente - SP

www.steelbras.com.br



INDÚSTRIA
BRASILEIRA



FEB/2024